
IMAGE EVALUATION TEST TARGET (MT-3)



Photographic Sciences Corporation

23 WEST MAIN STREET WEBSTER, N.Y. 14580 (716) 872-4503

STATE OF THE STATE

CIHM/ICMH Microfiche Series.

CIHM/ICMH Collection de microfiches.



Canadian Institute for Historical Microreproductions / Institut canadien de microreproductions historiques



C 1986

Technical and Bibliographic Notes/Notes techniques et bibliographiques

	12X	16X	20X		24X	28X		32X
This i Ce do 10X	tem is filmed at t ocument est filmé 14:	au taux de réc	atio checked below, duction indiqué ci-d 18X	/ essous. 22X	26	×	30X	
	Additional comm Commentaires su		;					
	Blank leaves added during restoration may appear within the text. Whenever possible, these have been omitted from filming/ Il se peut que certaines pages blanches ajoutées lors d'une restauration apparaissent dans le texte, mais, lorsque cela était possible, ces pages n'ont pas été filmées.				slips, tissues, etc., have been refilmed to ensure the best possible image/ Les pages totalement ou partiellement obscurcies par un feuillet d'errata, une pelur etc., ent été filmées à nouveau de façon à obtenir la meilleure image possible.			nt ne pelure.
	along interior ma	irgin/ peut causer de	l'ombre ou de la		Soule édition	disponible or partially o	bscured b	y errata
	Bound with other material/ Relié avec d'autres documents Tight binding may cause shadows or distortion				Includes supplementary material/ Comprend du matériel supplémentaire Only edition available/			
	Coloured plates and/or illustrations/ Planches et/ou illustrations en couleur				Quality of print varies/ Qualité inégale de l'impression			
	Coloured ink (i.e Encre de couleur	o. other than bl r (i.e. autre que	ue or black)/ s bleue ou noire)	\checkmark	Showthrough Transparence			
	Coloured maps/ Cartes géograph		ur		Pages detact Pages détact			
	Cover title missi Le titre de couve				Pages discol	oured, stained prées, tacheté	or foxed. es ou piqu	/ ıėes
	Covers restored Couverture resta				Pages restor Pages restau	ed and/or lan rées et/ou pe	ninated/ Iliculées	
	Covers damaged				Pages dama Pages endor			
V	Coloured covers Couverture de c				Coloured pa Pages de co			
The Institute has attempted to obtain the best original copy available for filming. Features of this copy which may be bibliographically unique, which may alter any of the images in the reproduction, or which may significantly change the usual method of filming, are checked below.			qu'i de : poi une mo	L'Institut a microfilmé le meilleur examplaire qu'il lui a été possible de se procurer. Les détails de cet exemplaire qui sont peut-être uniques du point de vue bibliographique, qui peuvent modifie une image reproduite, ou qui peuvent exiger une modification dans la méthode normale de filmage sont indiqués ci-dessous.				

The to t

The pos of t

Original Designation of the sion or illustration or illustrati

The shal TIN whi

Map diffe entir begi right requ met The copy filmed here has been reproduced thanks to the generosity of:

Library of the Public Archives of Canada

tails

s du

rune

mage

rata

elure.

odifier

The images appearing here are the best quality possible considering the condition and legibility of the original copy and in keeping with the filming contract specifications.

Original copies in printed paper covers are filmed beginning with the front cover and ending on the last page with a printed or illustrated impression, or the back cover when appropriate. All other original copies are filmed beginning on the first page with a printed or illustrated impression, and ending on the last page with a printed or illustrated impression.

The last recorded frame on each microfiche shall contain the symbol → (meaning "CONTINUED"), or the symbol ▼ (meaning "END"), whichever applies.

Maps, plates, charts, etc., may be filmed at different reduction ratios. Those too large to be entirely included in one exposure are filmed beginning in the upper left hand corner, left to right and top to bottom, as many frames as required. The following diagrams illustrate the method:

L'exemplaire filmé fut reproduit grâce à la générosité de:

La bibliothèque des Archives publiques du Canada

Les images suivantes ont été reproduites avec le plus grand soin, compte tenu de la condition et de la netteté de l'exemplaire filmé, et en conformité avec les conditions du contrat de filmage.

Les exemplaires originaux dont la couverture en papier est imprimée sont filmés en commençant par le premier plat et en terminant soit par la dernière page qui comporte une empreinte d'impression ou d'iliustration, soit par le second plat, selon le cas. Tous les autres exemplaires originaux sont filmés en commençant par la première page qui comporte une empreinte d'impression ou d'iliustration et en terminant par la dernière page qui comporte une telle empreinte.

Un des symboles suivants apparaîtra sur la dernière Image de chaque microfiche, selon le cas: le symbole → signifie "A SUIVRE", le symbole ▼ signifie "FIN".

Les cartes, planches, tableaux, etc., peuvent être filmés à des taux de réduction différents. Lorsque le document est trop grand pour être reprodult en un seul cliché, il est filmé à partir de l'angle supérleur gauche, de gauche à droite, et de haut en bas, en prenant le nombre d'images nécessaire. Les diagrammes suivants illustrent la méthode.

1 2 3	1	2	3
-------	---	---	---

1	
2	
3	

1	2	3
4	5	6

Sup. on Hestry house


GRAND TRUNK RAILWAY.

Regulations for the Use and Care

OF THE

Westinghouse Automatic
Air Brakes.

MONTREAL, JULY 1, 1883,




GRAND TRUNK RAILWAY.

Regulations for the Use and Care

OF THE

Westinghouse Automatic Air Brakes.

MONTREAL, JULY 1, 1883.



Automatic Air Brakes.

ENGINEMEN.

- r. Fill the oil cup on the pipe leading to the steam cylinder, with cylinder oil; open the cock in the bottom half a turn; this will lubricate the steam cylinder.
- 2. Start the pump gradually, to allow the condensed steam to escape; after the pump has made a few strokes, put a small quantity of cylinder oil into the cup on the air cylinder, to lubricate the air cylinder.
- 3. Always have a pressure of 65 pounds on the gauge before the engine is connected with the train.
- 4. When filling the reservoirs under the cars with air, the handle of the two-way cock must be turned to the left; this allows the air already pumped to pass from the main reservoir, reduces the pressure, and causes the pump to work more rapidly, until the gauge again indicates 65 pounds; the handle must then be turned to the centre position, so that the spring fits in the notch.
- 5. The brake is applied by turning the handle to the right from the notch, and exhausting ten or fifteen pounds of air.

- 6. When taking on extra cars, turn the handle to the left, to allow the reservoirs in the extra cars to fill with air; after this is done apply the brakes and let them off suddenly, to ensure all being released.
- 7. In making stops at stations, exhaust small quantities of air at a time; by so doing you reserve the air and bring the train to a stop gradually—releasing the brakes about the last revolution of the driving-wheels (as near as you can judge); by so doing you avoid those lurches noticeable in stopping a train with the power brake. Never apply the brakes with full force except in cases of emergency.
- 8. Avoid, as far as possible, applying the brakes a second time, if on the first application you find you are going to stop too soon, and you have to let them off to run a little farther; this second application will not be as strong as the first, because the reservoirs have not had sufficient time to re-fill, and there will be difficulty in releasing.
- 9. Run the pump as slowly as possible, and keep up the required pressure; the safety valve pops at 85 pounds.
- 10. Never use the brake in shunting trains, or when brakemen are expected to brake.
- the triple valve under the tender should be drained daily, to let out any water that may have collected; there are plugs for this purpose.

- 12. See that the tender brake hose is always hung up in the clip for the purpose whenever it is not in use; this will prevent dust getting into the triple valve. All brake couplings must be disconnected by hand. Remember that you are responsible for the condition of the brakes on the engine and tender.
- 13. For the automatic brake, the handle on triple valve must be turned horizontally; if turned down, will change it to the simple air brake; if turned midway between these two positions it will close communication with the brake cylinder and reservoir, and should be so turned when desirable to have the brakes out of use on any particular car, from breaking of rods, etc. This applies to tenders and cars.
- 14. When, from any cause, the automatic brake cannot be used, change to the simple air brake, but in this case remember that the brake valve on engine requires to be worked the opposite way.
- 15. Promptly test the brakes at the request of Car Inspectors at terminal and (whenever a car is taken on or put off) at intermediate stations, and obtain a notification that all is right before starting. The pump must not be worked while test is being made.
- 16. Enginemen must specially report upon arrival at terminal stations, or Round House, any defect in the working of their engine, valves, pump, etc., and on trip tickets particulars of all failures of the brakes and loss of time in connection therewith. All passenger engines must carry a spare hose and couplings, as part of their equipment,

TRAINMEN.

- In making up trains, all couplings must be united, so that the brakes will apply throughout the entire train. The cocks in the brake pipe must all be opened (handles pointing down) except that on the rear of the last car, which must be horizontal, and the coupling hung up in the clip.
- 2. In detaching engines or cars, the couplings must invariably be separated by hand; the cocks in the brake pipes must always be closed before uncoupling to prevent application of the brakes.
- 3. At stations where it may be necessary to cut the train, to take or leave cars, trainmen must not turn the stop cock or disconnect hose until the brakes have been released by the engineman.
- 4. If the brakes are applied when the engine is not attached to the train or car, they can be released by opening the cock in the end of the brake cylinder or air reservoir.
- 5. If cars are equipped with a valve for the application of the brakes from the inside it should be kept tight, and must always be examined when the car is standing at terminal stations. This valve must only be used in case of emergency.

- 6. The brakes must be tested at intermediate stations whenever a car is taken on or put off and inspected by the brakeman, to see that all are in working order. Conductors are responsible in such cases, and when trains start from points at which no inspectors are located, they must see that the test is properly made as per car inspector's rule number six.
- 7. If the packing in the couplings freeze so as to leak, thaw out with a torch.
- 8. Report to car inspectors any car not in working order.
- 9. Keep the hose coupled together or hung up in the clips provided for that purpose, when not in use.
- 10. The uncoupling of all brake hose is the duty of the brakemen.
- to the first duty or a Conductor, if his train should be stopped by reason of any accident to the brake gear, is to see that the rear of the train is protected, and to relieve the brakes by opening the cocks in the ends of cylinders or air reservoirs under each car as quickly as possible.

CAR INSPECTORS.

- 1. The adjustment of the brakes should be such that, when applied, the pistons in the brake cylinders will not travel to exceed seven or eight inches; this will allow room for wear of shoes, stretching of rods, springing of brake beams, etc., while on the road.
- 2. Great care must be exercised in taking up the slack in connections, to have the levers and pistons pushed back to their proper places, and the slack taken up by the under connections or dead lever.
- 3. The brake cylinders and triple valves must be always kept clean and free from gum, so that they will readily release when the air has been discharged; oil once a month with cil supplied for this purpose, and note the last date of oiling and station shop mark on the cylinders with chalk. A record of such oiling must be sent each week to the car superintendent at Montreal or London.
- 4. In damp weather the triple valve should be drained daily, to let out any water that may have collected. Slack the bottom nut about half a turn, let the water escape, and screw it up again; if there is a pet-cock, draw through that.

- 5. When the train is finally made up the inspector must take his position at the engine while the brake is being tested, that the engineman may inform him if any leak be discovered, which he must promptly attend to. He will then examine each car throughout the entire train, to see that the brakes have applied properly, and when all is right will notify the engineman, who requires such notification before starting.
- 6. Inspectors will be held responsible if trains leave stations with the air brakes not in perfect working order, and they are also responsible for the coupling of all hose.
- 7. Inspectors at all points must keep on hand, ready for immediate use, a supply of the parts that are liable to get out of repair, as well as tools necessary for making repairs.

Enginemen and conductors will report promptly any neglect to comply with these rules.

W. J. SPICER, C. STIFF,

it, ot

of

k

d

y

e

11

il

d n st

ιl

d

Superintendents.

HERBERT WALLIS,
C. K. DOMVILLE,
Mechanical Superintendents.

For illustration of the following, see diagram below:

A represents valve at ends of car.

When a train is made up, the handle MUST be in position as shown at D, except at rear end of rear car, where it must be as shown at C before starting the train. Before uncoupling train from engine, the handle on end of car next to engine must be as shown at C. Before UNCOUPLING CARS, it must also be placed at C. B represents the triple valve under car. When the handle is at G, it is right for automatic; when at E, for the old pressure brake. When any part of the brake apparatus of a car is broken or out of order, so that it cannot be used, place the handle at F (except in cases of BROKEN HOSE, or leaky PIPES). In case a HOSE bursts, or there is a leak in the PIPES that applies the brakes, turn the handle of valve A to C on rear end of the next car ahead of the leak; then turn handle of valve B to E on car with the leak, and all cars in the rear of it.

