Rule LXXXIII.—Bulwarks

The ship must be fitted either with permanent bulwarks at least 3 feet 3 inches high, specially stiffened on the upper edge and supported by strong bulwark stays attached to the deck in the way of the beams and provided with necessary freeing ports, or with efficient rails of the same height as the above and of specially strong construction.

Rule LXXXIV.—Deck Openings covered by Timber Deck

Openings to spaces below the freeboard deck are to be securely closed and battened down. All fittings, such as hatchway beams, fore-and-afters, and covers, are to be in place. Where hold ventilation is needed, the ventilators are to be efficiently protected.

Rule LXXXV.—Stowage

The wells on the freeboard deck are to be filled with timber stowed as solidly as possible, to at least the standard height of a bridge.

On a ship within a seasonal winter zone in winter, the height of the deck cargo above the freeboard deck is not to exceed one-third of the extreme breadth of the ship.

All timber deck cargo is to be compactly stowed, lashed and secured. It must not interfere in any way with the navigation and necessary work of the ship, or with the provision of a safe margin of stability at all stages of the voyage, regard being given to additions of weight, such as those due to absorption of water and to losses of weight such as those due to consumption of fuel and stores.

Rule LXXXVI.—Protection of Crew, Access to Machinery Space, &c.

Safe and satisfactory access to the quarters of the crew, to the machinery space and to all other parts used in the necessary work of the ship, is to be available at all times. Deck cargo in way of openings which give access to such parts is to be so stowed that the openings can be properly closed and secured against the admission of water. Efficient protection for the crew in the form of guard rails or life lines, spaced not more than 12 inches apart vertically, is to be provided on each side of the deck cargo to a height of at least 4 feet above the cargo. The cargo is to be made sufficiently level for gangway purposes.

Rule LXXXVII.—Steering Arrangements

Steering arrangements are to be effectively protected to from damage by cargo, and, as far as practicable, are to be accessible. Efficient provision is to be made for steer