

**THE FOLLOWING TABLE GIVES THE  
DIMENSIONS OF STUD AND CLOSE-LINK CHAINS,**

which we would recommend for use upon our Windlasses, and adopted by the  
leading chain manufacturers in the United States :—

Size OF CHAIN CABLES. Inches.	STUD-LINK.		CLOSE-LINK.		AVERAGE WEIGHT PER FATH.	
	Outside Length. Inches.	Outside Width. Inches.	Outside Length. Inches.	Outside Width. Inches.	Stud-Link. Pounds.	Close-Link. Pounds.
$\frac{1}{8}$			2 $\frac{1}{4}$	1 $\frac{1}{4}$		15
$\frac{1}{4}$			2 $\frac{3}{4}$	1 $\frac{1}{2}$		19
$\frac{3}{8}$			3	2 $\frac{1}{4}$		25
$\frac{1}{2}$			3 $\frac{1}{2}$	2 $\frac{3}{4}$		30
$\frac{5}{8}$	4 $\frac{1}{2}$	2 $\frac{3}{4}$	3 $\frac{3}{4}$	2 $\frac{3}{4}$	33	35
$\frac{3}{4}$	4 $\frac{3}{4}$	3	3 $\frac{7}{8}$	2 $\frac{3}{4}$	38	40
$\frac{7}{8}$	5	3 $\frac{1}{4}$	4	3	43	47
1	5 $\frac{1}{2}$	3 $\frac{1}{2}$	4 $\frac{1}{2}$	3 $\frac{1}{4}$	50	54
1 $\frac{1}{8}$	5 $\frac{3}{4}$	3 $\frac{3}{4}$	4 $\frac{3}{4}$	3 $\frac{3}{4}$	57	60
1 $\frac{1}{4}$	6	3 $\frac{7}{8}$	5	3 $\frac{7}{8}$	63	67
1 $\frac{3}{8}$	6 $\frac{1}{4}$	4	5 $\frac{1}{2}$	3 $\frac{7}{8}$	71	74
1 $\frac{1}{2}$	6 $\frac{3}{4}$	4 $\frac{1}{4}$	5 $\frac{3}{4}$	4	76	82
1 $\frac{5}{8}$	7	4 $\frac{1}{2}$	6	4 $\frac{1}{4}$	83	90
1 $\frac{7}{8}$	7 $\frac{1}{4}$	4 $\frac{3}{4}$	6 $\frac{1}{2}$	4 $\frac{3}{4}$	92	98
2	7 $\frac{3}{4}$	5	6 $\frac{3}{4}$	5	105	108
2 $\frac{1}{8}$	8	5 $\frac{1}{2}$	6 $\frac{7}{8}$	5 $\frac{1}{4}$	110	118
2 $\frac{1}{4}$	8 $\frac{1}{4}$	5 $\frac{3}{4}$	6 $\frac{7}{8}$	5 $\frac{1}{4}$	122	128
2 $\frac{3}{8}$	8 $\frac{3}{4}$	5 $\frac{7}{8}$	7	5 $\frac{3}{4}$	133	138
2 $\frac{1}{2}$	9	6	7 $\frac{1}{4}$	5 $\frac{3}{4}$	145	156
2 $\frac{5}{8}$	9 $\frac{1}{4}$	6 $\frac{1}{4}$			152	
2 $\frac{3}{4}$	10	6 $\frac{1}{2}$			165	
3	10 $\frac{1}{4}$	6 $\frac{3}{4}$			179	
3 $\frac{1}{8}$	10 $\frac{3}{4}$	6 $\frac{3}{4}$			195	
3 $\frac{1}{4}$	10 $\frac{3}{4}$	7			209	
3 $\frac{3}{8}$	11 $\frac{1}{4}$	7 $\frac{1}{4}$			225	
3 $\frac{1}{2}$	11 $\frac{3}{4}$	7 $\frac{3}{4}$			250	
3 $\frac{5}{8}$	12	7 $\frac{3}{4}$			280	
4	12 $\frac{1}{4}$	8			300	
4 $\frac{1}{8}$	13	8 $\frac{1}{4}$			325	
4 $\frac{1}{4}$	13 $\frac{1}{4}$	8 $\frac{1}{2}$			350	
4 $\frac{3}{8}$	13 $\frac{3}{4}$	8 $\frac{3}{4}$			375	
4 $\frac{1}{2}$	14	9			400	
4 $\frac{3}{4}$					425	

We recommend Stud-Link Chains in all cases as being cheaper and stronger  
and better adapted to work on iron windlasses.