

- entlases, 625; tools, 625; how to temper plane irons, drawing knives, &c., 625; cold chisels, stone drills, &c., 625; to temper taps or reamers, 625; to harden and temper cast steel, 625; to temper small springs in large quantities, 625; razors, saws, cutlery, &c., 626; a practice to be deprecated, 626; heating of the blades, 626; how razors are tempered, 626; how they are cooled, 626; tempering pen blades, 626; edge tools, 626; the use of oil or resinous mixtures in tempering, 626; how gun lock springs are treated, 626.
- Case-hardening compound, 625.
- Turning and boring, 626; the proper speed for turning, 626; the best speed for boring cast iron, 627; the best speed for drilling, 627; boring a hole with a boring tool, 627; boring holes without arbor, 627; to drill a hole without a reamer, 627; to make a boring arbor and tool that will not chatter, 628; to straighten shafting, 627; turning shafting, 627; to forge a twist drill, 627; to compute the number of teeth required in a train of wheels to produce a given velocity, 628; to compute the diameter of a wheel, 628; paper friction pulleys, 628; on belting and friction, 628; wheel gearing, 629; galvanized iron, 630; to form perfect squares, 630.
- Wood, to protect from the influences of air or water, 630; to remove stains from, 631; to stain, 631; action of water on lead, 632; to remove rust from steel, 632; to preserve metals from rust, 632; to remove or keep rust from cutlery, 633; to prevent iron or steel from rusting, 633; steel, prevention from rust, 633; springs, 633; shrinkage of castings, 633; effects of heat on various bodies, 634; water pipes, to prevent freezing, 634; refining fluxes for metals, 634; flux for welding copper, 634; Cornish reducing flux, 634; paste for cleaning metals, 634; sinning, 634; to cloud metal work, 634; tinning acid for brass or zinc, 634; tinning cast iron, 634; bronze paint for iron or brass, 635; to bronze iron castings, 635; removing zinc and iron from plumber's solder, 635; solution of copper or zinc, 635; bronze to remove stains from, 635; to reduce oxide of zinc, 635; bronzing liquids for tin castings, 635; to tin copper and brass, 635; to separate tin from lead, 635; to clean and polish brass, 635; brass solution, 635; brassing iron, 635; to refine copper, 635.
- The steam engine, diagram of condensing steam engine with references to names of the various parts, 636; works recommended for careful study in reference to, by those desiring to be fully posted, 636.
- Iron lustré, how it is obtained, 636.
- Fancy colors on metals, how to produce, 636.
- To cast brass solid, instruction how, 636.
- Mechanical movements, for inventors, model makers, &c., consisting of one hundred and forty different forms of motion, fully illustrated and explained, 637, 638, 639, 640, 641, 642, 643.
- Tabular statement of alloys, their melting heat, and fluxes, 644.
- Bottle glass, fourteen formulas for, 644.
- Best window glass, nine formulas for, 644.
- Glass staining, the process of applying colors, and burning them in, 645; eleven formulas to produce as many various colors, 645.
- Soluble glass, three distinct formulas for making, 646.
- To cut glass, 646.
- Stained glass pigments, six separate and distinct colors, 646.
- Neat's foot oil, how to produce, 646, 647.
- Economic lubricators, five descriptions for various purposes, 647.
- Patent lubricating oil, 647.
- Watchmaker's oil, 647.
- Glue, to manufacture, 647; how to strengthen, 647.
- Cement, for joints of iron pipes or holes in castings, 649; best for aquaria, two kinds, 649; strong for steam joints, 649; air and water tight, for casks and cisterns, 649; for gasfitters, 649; for plumbers, 649; for coppersmiths, 649; for external use, 649; to resist red heat, and boiling water, 649; to join sections of cast-iron wheels, &c., 649; for mending stone and earthenware, 649; for mending china, 649; Vicat's hydraulic, 650; jewellers, 650; for alabaster, 650; for ironware, 650; transparent for glass, 650; for petroleum lamps, 650; for lute, 650; Roman, 650; sealing, 651.
- To cement broken china, 649, 650.
- Asbestos powder as a cement, 650.
- Rust joint, quick setting, two kinds, 650.
- Jewellers' Armenian cement, 650.
- Ink, lithographic, 651; indelible, for marking linen without preparation, 651; black stencil, 651; indelible stencil, 651; blue ruling, 651; black ruling, 651; Prof. Bottgers, portable, 651; ticketing ink for grocers, 651; premium black writing, 651; superior blue, 651; horticultural, 651; formulas for sixteen varieties for different purposes, 651, 652; luminous, shines in the dark, 652; yellow, 652; invisible, 652; red ruling, 652; marking, 652; marking, 653; sympathetic, 653; writing, 653.
- Sealing wax, how to make, 653.
- On melting and refining, 654.
- Black, having a polish for iron, 654.
- The national coins of the United States, how much pure metal they contain, 654.
- How the fineness of gold used for coin, jewellery, &c., is estimated, 654.
- The standard for gold and silver coins of the United States, 654.
- To clean light kid gloves, 654.
- Waterproof for porous cloth, 654.
- To restore rusty Italian crapes, 654.
- Potter's invisible waterproofing, 654.
- Knots and how to tie them, fifty-one different methods illustrated, 652, 653.
- Billiard balls, different positions of the cue, to accomplish certain strokes, 653.
- Measures of length, illustrated table, 651.