

doors on that floor. Where there are no balcony doors one or more window grills must be hinged to provide an escape route in the event of fire.

It is necessary to have an extension telephone in the safe haven so that the police can be summoned in the event of an attack. In some areas where telephones are unreliable, two-way radios have been provided.

Padlocks, cylinder locks and strong sliding bolts can be used to secure overhead, sliding, swinging or accordion-type garage door.

Have your plan of escape from fire and other emergencies prepared and discussed in advance with other occupants.

RESIDENTIAL DETECTORS AND ALARMS

The following is a description of types of alarms which have been installed at some posts.

Single Station Alarms

These are usually simple battery-operated high-pitched buzzers which are connected to the external doors and windows. The sound intensity of the buzzer is loud enough to awaken most household members and frighten off most intruders.

portes de balcon de cet étage. Lorsqu'il n'y a pas de portes de balcon, une ou plusieurs fenêtres grillagées doivent être à charnières, afin de pouvoir s'en servir comme sorties de secours en cas d'incendie.

Il est indispensable d'avoir un téléphone supplémentaire dans l'abri provisoire afin que la police puisse être appelée en cas d'attaque. Dans certains districts où les services téléphoniques sont instables, on a prévu des liaisons radio bilatérales.

Des cadenas, des serrures à barillet (dites serrures américaines ou Yale) et de solides verrous coulissants peuvent être utilisés pour les portes de garage basculantes, coulissantes, battantes ou du genre accordéon.

Préparez d'avance votre plan de sauvetage en cas d'incendie ou autres situations d'urgence et discutez-en avec les autres occupants.

DISPOSITIFS DE DÉTECTION ET D'ALARME

Une description des dispositifs installés à des missions est donnée dans l'énoncé ci-après.

Dispositif d'alarme à poste unique

Ce sont généralement des dispositifs simples à batterie produisant un son aigu (en d'autres termes une sonnerie), qui sont reliés aux portes et fenêtres extérieures. La grande intensité du son suffit à réveiller presque toute la maisonnée et à effrayer la plupart des intrus.