Swab-stick, a stick frayed at one end for cleaning out holes.
Synclinal, the trough formed by folded strata, the reverse of anticlinal.

Tailings, the refuse from crushing-mills or concentrators. Tamping, making a loaded hole tight with clay.

Terrane, a group of strata.

Throw, fault.

Till, hard pan, boulder clay.

Tribute, a system of paying miners according to value of ore which they extract.

Trouble, fault.

Tuberose, bulb-like.

Tunnel, a horizontal entry to a mine, across country rock.

Underholing, see Holing.

Upcast, an opening through which air rises.

Upraise, a secondary passage from one level up to another.

oose ground.

in alluvial

re walls.

Van, to dress or concentrate ore. Vanner, a concentrating machine. Vug, a cavity in a rock.

of a car and

Wall-plate, the long horizontal stick in a shaft-timbering frame and parallel with the vein.

Wet Ores, applied to silver ores, high in lead, and low in silver. Whim, a horizontally revolving drum for winding hoisting rope, operated by a horse.

nined in the

Whip, a hoisting rope supported by a pulley operated directly by a horse.

port roof or

Winch, windlass, a hoisting drum operated by hand. Winze, a secondary opening sunk from a level.

s or strata. transmitting

nineral from

l, silver, tin

g miners o

es.
which the