

ART.		PAGE
20.	Position of Uniform Live Load causing Maximum Chord Stresses . . . . .	54
21.	Maximum Stresses in the Chords . . . . .	55
22.	Position of Uniform Live Load causing Maximum Shears . . . . .	57
23.	The Warren Truss . . . . .	60
24.	Mains and Counters . . . . .	70
25.	The Howe Truss . . . . .	74
26.	The Pratt Truss . . . . .	81
27.	The Warren Truss with Vertical Suspenders . . . . .	84
28.	The Double Warren Truss . . . . .	87
29.	The Whipple Truss . . . . .	90
30.	The Lattice Truss . . . . .	94
31.	The Post Truss . . . . .	98
32.	The Bollman Truss . . . . .	100
33.	The Fink Truss . . . . .	101
34.	The Parabolic Bowstring Truss . . . . .	103
35.	The Circular Bowstring Truss . . . . .	108
36.	Snow Load Stresses . . . . .	109
37.	Stresses due to Wind Pressure . . . . .	110
38.	The Factor of Safety . . . . .	118

## CHAPTER III.

BRIDGE TRUSSES WITH UNEQUAL DISTRIBUTION  
OF THE LOADS.

39.	Preliminary Statement . . . . .	120
40.	When the Uniform Train Load is preceded by One or More Heavy Excess Panel Loads . . . . .	120
41.	When One Concentrated Excess Load accompanies a Uniform Train Load . . . . .	127
42.	When Two Equal Concentrated Excess Loads accompany a Uniform Train Load . . . . .	133
43.	The Baltimore Truss . . . . .	142
44.	True Maximum Shears for Uniform Live Load . . . . .	154
45.	Locomotive Wheel Loads . . . . .	157