




## Boiler Connections



Showing correct method of connecting equalizing pipe from flow main to the return entering boiler.