

- # 12
- (i) Remove the gear box and shutter from the camera body.
 - (ii) Place the body and case in mounting and secure.
 - (iii) Place a sheet of ground glass (ground side down) on the pressure glass. Adjust tilt and aft and astward ship until desired angle of view is obtained (This should show tail wheel approximately 2" down on pressure glass.)
 - (iv) Lock adjustment nuts and note position of camera body in mount.
 - (v) Remove camera body and replace gear box and shutter.
 - (vi) Place camera back in mount adjust to noted position and lock.
 - (vii) Test camera operation:
 - (a) independently of bomb circuit.
 - (b) with bomb circuit--This test should be made only when an armour or electrician are present

(6) LOADING THE CAMERA.

- (1) Electrically operate camera until 17 exposures have been run off then stop by removing power plug from the wall receptacle.
- (2) Place loaded magazine on camera and run off remaining three exposures by placing power plug back in the wall socket.