




No. 11. Easel.
Price 10 Cents.
Size 8 x 11 in.



No. 12. Easel.
Price 10 Cents.
Size 7 x 9 1/2 in.




No. 13. Holder for Grass Bouquet
(carved). Price 10 Cents.
Size 5 x 8 in.




No. 14. Match Box.
Price 5 Cents.
Size 6 x 9 in.



No. 15. Corner Bracket or Book
Shelf. Price 10 Cents.
Size 6 x 18 in.



No. 16. Easel.
Price 5 Cents.
Size 7 x 10 in.



No. 17. Picture Frame (carved).
Price 10 Cents.
Size 8 by 11 in.




No. 18. Side to Hanging
Basket. Price 10 Cents.
Size 5 x 5 1/2 in.




No. 19. Corner Cabinet, Bracket
Support. Price 25 Cents.
Size 8 by 10 in.




Corner Cabinet. Top Frame
for No. 19.
Size 8 by 10 in.



No. 20. Swiss Clock.
Price 15 Cents.
Size 8 1/2 x 11 in.



Top to Clock, No. 20.




Front for Clock, No. 20.
Size 5 1/2 x 7 1/2 in.




No. 21. Thermometer Frame.
Price 10 Cents.
Size 4 1/2 x 10 in.




No. 22. Small Wall Pocket.
Price 10 Cents.
Size 7 1/2 x 8 1/2 in.



Stand for No. 20.



No. 23. Wall Pocket.
Price 15 Cents.
Size 9 x 16 in.



No. 24. Combined Bracket, Picture
Frame, and Match Box. Price 15 Cents.
Size 11 x 15 in.



No. 25. Small Wall Pocket.
Price 10 Cents.
Size 8 x 10 in.



No. 26. Large Wall Pocket.
Price 15 Cents.
Size 12 x 14 in.