

Rule CV.—*Winter North Atlantic Freeboard*

The minimum freeboard for voyages across the North Atlantic, north of latitude 36° N., during the winter months, is the Winter Freeboard plus an addition at a rate of 1 inch per 100 feet in length.

Rule CVI.—*Freeboard Table for Tankers*

L in Feet.	Freeboard in Inches.	L in Feet.	Freeboard in Inches.
190	21.5	400	62.5
200	23.1	410	64.9
210	24.7	420	67.4
220	26.3	430	69.9
230	28.0	440	72.5
240	29.7	450	75.1
250	31.5	460	77.7
260	33.3	470	80.2
270	35.2	480	82.7
280	37.1	490	85.1
290	39.1	500	87.5
300	41.1	510	89.8
310	43.1	520	92.1
320	45.1	530	94.3
330	47.1	540	96.5
340	49.2	550	98.6
350	51.3	560	100.7
360	53.5	570	102.7
370	55.7	580	104.6
380	57.9	590	106.5
390	60.2	600	108.4

Ships above 600 feet are to be dealt with by the Administration.

ANNEX II.

BOUNDARIES OF THE ZONES AND SEASONAL AREAS.

Zones.

The southern boundary of the northern "Winter Seasonal" zone is a line drawn from the east coast of North America along the parallel of lat. 36° N. to Tarifa in Spain; from the east coast of Korea along the parallel of lat. 35° N. to the west coast of Honshiu, Japan; from the east coast of Honshiu along the parallel of lat. 35° N. to long. 150° W., and thence along a rhumb line to the west coast of Vancouver Island at lat. 50° N., Fusan (Korea) and Yokohama to be considered as being on the boundary line of the northern "Winter Seasonal" zone and the "Summer" zone.

The northern boundary of the "Tropical" zone is a line drawn from the east coast of South America at lat. 10° N. along the parallel of lat. 10° N. to long. 20° W., thence

PUSAN - corrected
by letter from U.K. Trade
Commissioners of
Oct 6, 1960 -
F. 2468-40.