

- What to do, when engine explosions are regular but weak, 74, 91
when engine hisses, 74, 110
when engine knocks, 75, 91, 110
when the engine misfires, 74, 92, 110
when engine overheats, 75, 110
when the engine races, 92
when engine smokes, 74
when engine won't start, 73, 91, 109
when the engine stops, 91, 110
when explosions occur in muffler, 75, 92, 110
when the explosions are regular but weak, 110
when ready to go, 21
when there is a decrease in power, 92
- What you can fix on your car, 151
- What not to do, 158
- What's what in car bodies, 7
- When your car is in the garage, 158
- When you have a breakdown on the road, 165
- Wheel, removable, 42
- Wheels, 37
- Why the spark must be timed, 108
- Windows, cleaning, 187
- Windshield, to keep dry, 187
- Winter, how to take care of your car in, 136
storing your car for the, 187
when zero weather sets in, 136
- Winter weather, anti-freezing solutions for, 136
- Wire, proper size for electric lamps, 146
- Wire wheels, 38
- Wiring up electric lamps, 145
- Wood wheels, 38
- Wrist pin, 70
- Zero weather, when it sets in, 136