
DOBBIE & STEWART

THOROLD, ONT.



MANUFACTURERS OF

—о**г**—

HORSE POWER HOISTING MACHINES

---FOR---

Ore and Coal Mining; also for Railroad Contractors and Quarrymen.



JEFFREY COAL MINING MACHINES

OPERATED BY ELECTRICITY AND AIR POWER.

Coal Drills, Motor Cars, Etc., Etc.

COAL SCREENS

MINES EXAMINED AND ESTIMATES MADE. Send for Catalogue.



THE JEFFREY MANUFACTURING COMPANY,

218 East 1st Ave., Columbus, O.

MINING AND MILL MACHINERY.

Steam Engines, Rock Crushers, Boilers, Derricks, Steam Pumps, Water Wheels, Brass and Iron Castings of every description.

ALEX. FLECK, VULCAN IRON WORKS, WELLINGTON STREET, OTTAWA.

J. S. HOSSACK, President.

C. ANDERSON, Secretary-Treasurer.

T. J. CARROLL, General Manager.

FAMILTON BRASS MFG. CO.,

ENGINEERS' AND PLUMBERS' BRASS GOODS.

259 & 261 James Street N.,

HAMILTON, ONT.

STATIONERY, MARINE, PORTABLE, AND LOCOMOTIVE BOILERS.

Simple, Reliable and Durable. Every Injector Guaranteed for Two Years.

Range, 25 to 150 lbs., and is the only Automatic Injector in the world that can be operated by opening one valve, and that the overflow. Can have a pipe connected to conduct the overflow to tank or sewer. The only Injector having a Signal Valve to show when the Injector is working; all other boiler feeders not having this cannot be connected to return the overflow to tank or sewer.

OUR PROPOSITION:

As every Injector is tested before it leaves the factory, we know that if properly connected (as in diagram) and instructions are carried out, they cannot fail to work. We therefore offer to pay the expenses of any man to come to the factory, and \$25.00 per day while there if the Injector does not work, provided it has not been misused.

As the body will last for years, it is only necessary to order working parts to make injector good as new. Every purchaser can repair his own Injector without sending it to the factory.

	- H	- HAMILTON, ONT.		
GEAM FROM BOILER	Number.	Price.	Horse Power.	
	7½ 8¾	\$ 4 50 6 00	4 to 8 8 to 12	
THE	10	7 00	12 to 16-	
IMPROVED FORCE	121/2	9 00	16 to 28	
AutoMAIC AutoMAIC	15	10 50	28 to 40-	
AUTOMATIC	171/2	14 00	40 to 57	
Trace Tone	20	15 00	57 to 72	
INJUANO INTERPRETATION	22 1/2	21 00	72 to 93	
Mode of	25	22 50	93 to 120	
CONNECTING	30	27 00	120 to 160-	
CONNEC	35	30 00	160 to 220-	
	40	35 00	220 to 290.	
	45	38 00	290 to 308	
	•	•	•	