the pit banks, screens and sidings, and of all the workmen employed thereon.

125. He shall see that the requirements of Section 4 of the C.M.R.A., 1911, as to the employment of boys above ground are complied with.

126. He shall be in attendance in the morning, or at such other time of the day as the miners' shift commences, and shall see that no person is allowed to go upon the cage until the engineman has ascertained and reported the safety of so doing, in terms of Special Rule 113, and shall regulate the number of men descending at a time, in accordance with the number specified on the notice board at the pithead. If a greater number get into a cage, he shall forbid the engineman to lower the cage until the excess in number leave it; and if the excess in number when ordered by him do not immediately leave the cage, he shall report the names of all the persons in it to the overman for investigation.

127. The pitheadman and engineman respectively shall prevent from going down the shaft or entering the mine any person not employed therein. or not duly authorized, unless by the special order or direction of the owner, agent, manager or overman.

128. He shall not allow any person to descend the shaft before or after the time fixed without permission from the proper authority.

129. When the shaft is used for raising or lowering material, and there are two ropes in the shaft, he shall not allow any person to get on to