

11. A fusee, on or near the track, burning red, must not be passed until burned out. When burning yellow, it is a caution signal. Fusees must not be used near public crossings, or on bridges, or where they may communicate fire.

12. HAND, FLAG, AND LAMP SIGNALS.

MANNER OF USING.	INDICATION.
(a) Swung across the track.	Stop.
(b) Raised and lowered vertically.	Proceed.
(c) Swung vertically in a circle across the track.	} Back.
(d) Swung vertically in a circle at arm's length across the track.	
(e) Swung horizontally in a circle.	} Train has parted. } Answer to 14 (j). } Apply air brakes.
(f) Held at arm's length above the head. If not responded to, lowered slowly to the ground and raised slowly again to the position above head.	
	} Release air brakes.

13. Any object waved violently by any one on or near the track is a signal to stop.