Directions

The slot in centre of Cutter should fit the projection on the end of the forcer. The thumb nut should be screwed tight enough to give only slight resistance to the crank; for chopping raw meat it should be tighter.

Meat to be chopped should be cut in strips; everything else in pieces small enough to be dropped into the hopper.

Dried bread or biscuit run through the machine will cleanse it. Rinse in hot water before putting away.

Sausage Stuffer

All 25 and 30 Food Choppers are made so that the stuffer attachment can be screwed on and used for stuffing sausages.



STUFFER ATTACH

Furnished at a slight a.

t the rpentear,

s are

tters, 165. I cutr No.

Nos.

, also dried

k for when

fruit,

oked food

eanut o not

meat erize