INDEX. v

	PA(3E
O 2.—Passenger steamers over 75 tons gross, and under 150 tons gross, may carry twelve buckets, three axes, and three lanterns	:	21
L 2.—Freight steamers to carry fire buckets, axes and lanterns according to their requirements, to the satisfaction of the Inspector]	16
Precautions against Fire.		
P 1.—Combustible materials to be not less than six inches from the boiler or other heated surfaces, and where so exposed, shall be properly shielded by some incombustible material. The open space must admit of the air circulating freely. Metallic vessels to be provided for waste or other inflammable substances.		8
P 2.—Inflammable matter to be stowed away as far as		•
possible from the boiler		20
Fire Engine Pumps on Passenger Steamboats.		
Q 1.—Every passenger steamer over 500 tons gross to have three double acting fire engine pumps, one of which may be worked by steam, which may be the pony pump, if not less than four inches diameter in the plunger. Passenger steamboats under 500, and over 200 tons, to have one double acting fire engine pump, and one steam pump, which may be the pony pump, if not less than four inches diameter in the plunger. Passenger steamboats under 200 tons to have one double acting four inches hand fire engine pump, which may be the pony pump if of similar dimensions.	0	20
Q 1.—Rule first: Steamboats requiring only one pump,	8,	30
it may be placed at the discretion of the Inspector.	8,	30
Q 2.—Every steamboat under 100 tons may have a steam or hand pump of suitable dimensions	19,	23
R 1 and 2.—Every steamboat over 60 tons register to have a steam pony pump for the supply of the boiler	9,	29
Position of Pumps.		
Q 1.—When three pumps are used, they are to be placed, one forward, one aft, and one amidships	8,	30
Q 2.—When one pump is used, it may be placed at the discretion of the Inspector, and where two pumps are used, they may be placed at the discretion of the owner.	•	2 3
Fire-pump Hose.		
Q 1.—In steamboats over 500 tons, the hose to each pump to be two-thirds the length of the vessel	8.	30
Q 2.—In steamboats under 500 tons, the hose must reach easily to all parts of the vessel. The hose in all cases to be coupled and ready for immediate use,		
with a hose wrench chained to the pump	19,	23
Iron Tubing in connection with Fire-engine Pumps.		
Q 3.—Length of hose may be shortened by the use of iron-tubes, as a substitute for hose	,	23