## ARTICLE 10

### Zones and Seasonal Areas

A ship to which this Convention applies shall conform to the conditions applicable to the zones and seasonal areas described in Annex II to this Convention.

A port standing on the boundary line between two zones shall be regarded as within the zone from or into which

the ship arrives or departs.

### CHAPTER III.—CERTIFICATES

#### ARTICLE 11

## Issue of Certificates

A certificate, called "International Load Line Certificate," shall be issued to every ship which has been surveyed and marked in accordance with this Convention, but not otherwise.

An International Load Line Certificate shall be issued either by the Government of the country to which the ship belongs or by any person or organization duly authorized by that Government, and in every case the Government assumes full responsibility for the certificate.

#### ARTICLE 12

# Issue of Certificates by another Government

The Government of a country to which this Convention applies may, at the request of the Government of any other country to which this Convention applies, cause any ship which belongs to the last-mentioned country, or (in the case of an unregistered ship) which is to be registered by the Government of that country, to be surveyed and marked, and, if satisfied that the requirements of this Convention are complied with, issue an International Load Line Certificate to such ship, under its own responsibility. Any certificate so issued must contain a statement to the effect that it has been issued at the request of the Government of the country to which the ship belongs, or of the Government by whom the ship is to be registered, as the case may be, and it shall have the same force and receive the same recognition as a certificate issued under Article 11 of this Convention.

#### ARTICLE 13

## Form of Certificate

The International Load Line Certificates shall be drawn up in the official language or languages of the country by which they are issued.