

Method**To modify the Tool Bar:**

1. Click on **OPTIONS** from the Menu Bar.
2. Select **TOOL BAR LAYOUT**.
3. To delete an existing button, click on the button in the preview Tool Bar and click on **DELETE**.
4. To add a button, select the function you want to add, click on the **NEW BUTTON**, and follow by clicking on **ADD**.
5. Repeat steps 3 and 4 until the Tool Bar is customized to your specifications. (Use **COMPRESS** to fill in any blanks in the Tool Bar.)
6. Click on **OK**.

Exercise

In this exercise, you will change the default Tool Bar Layout.

1. Click on **OPTIONS** in the Menu Bar
2. Select **TOOL BAR LAYOUT**
3. Click on the **EXTRFWD** button in the preview Tool Bar
4. Click on **DELETE**
5. Select **MOVE** from the functions available
6. Click on **NEW BUTTON** and click on **ADD**
7. Click on **OK**