

Centre Line assumed to extend from West to East, and Cross Sections from North to South. Formation Level at intersections is the Datum of each Cross Section.

Distance or Station.	Station. 201	Station. 202	Station. 203	Station. 203+50	Station. 293+75
Change of Gradient or rise per 100 feet.	Level.	Level.	Change.	1 per 100.	1 per 100.
Surface.	393.25	393.60	394.00	393.55	392.25
Formation....	393.00	393.00	392.00	392.50	392.25
Cutting.	0.25	0.60	1.00	1.05
Filling.....
<div> <div> <div>NORTH OF CENTRE LINE.</div> <div>CROSS SECTIONS.</div> <div>SOUTH OF CENTRE LINE.</div> </div> <div> <p>NOTE.—The first column is for distances north or south from centre line; the second column is for heights above and depths below formation level; those above to be marked +, and those below —: Slope stakes to be indicated in the notes, by a circle round the Distance, thus (24), or thus, S.S. 24.</p> </div> </div>					
				30 —8.00	40 —18.00
		30 +5.50	30 +0.20	(18) —6.00	30 —15.00
30 —1.10	(21) +4.00	(9) 0.00	9 —1.00	(24) —10.00	
(15) 0.00	15 +4.00	6 +1.00	6 0.00	9 —6.00	
0 +0.25	0 +0.60	0 +1.00	0 +1.05	0 0.00	
15 +1.00	15 +3.00	10 +2.00	15 +3.20	6 +2.00	
(24) +6.00	(27) +8.00	15 +2.50	(19.8) +3.20	15 +3.30	
30 +11.60	40 +10.00	(28.6) +9.00	30 +6.00	(21) +4.00	
		40 +8.50			