

HYDRANTS, GATE VALVES, AIR VALVES, RELIEF VALVES, ETC.

"COREY" STANDARD



Directions for Ordering Hydrants:

1st. Give size of valve opening or inside diameter of Standard Pipe.

2nd. Give length from surface of ground to bottom of connection Pipe.

3rd. Give size of bottom connecting. Pipe Hydrants for Wood Pipe have Hub or Bell Ends.

These rules govern in ordering any make of Hydrants.

In Ordering Valves:

Always give number pounds pressure, or head under which Valves are to work.

We can furnish any make of Standard Hydrant desired, and can be shipped with orders for pipe.

PRICES QUOTED ON APPLICATION