

PANDORA RANGE

The easiest way to remove ashes from a range is with an ash pan—the Pandora method (see illustration).

Such an extra large ash pan is provided with the Pandora that it will contain more ashes than will accumulate in one day.

All the ashes are in the pan, too, because they are guided there by flanges attached to either end of the fire-pot.

Easiest, cleanest, quickest, is the Pandora way.

With the scraper and pan provided with every Pandora it's merely a matter of a minute or so to clean out the dirt in the Pandora flues.

Less dirt accumulates in Pandora flues than in ordinary flues, because they are wider and deeper, with no bolts, projections or crevices to catch the dirt, consequently you need not clean them out so often.

Saves a lot of labor, does the Pandora.

If your local dealer does not sell the Pandora write direct for **Free Booklet.**

McClary's

London, Toronto, Montreal, Winnipeg,
Vancouver, St. John, N.B., Hamilton, Calgary

