

	Rule No.	Page
Incompetence.....	9, 336, 345,	350
Indicator, definition of.....		501
Injectors, overflowing on Interlocking plants.....		667
Injuries, personal, reports of.....		245
" personal, instructions in case of.....	700-716	
Inspection of Boarding cars.....		278
" Bolts.....		125
" Bridges and culverts.....	312-325	
" Chimneys and stove pipes.....		334
" Electric Bells.....	28-30, 692	
" Hand, motor and push cars.....	261, 263	
" Insulated joints.....		692
" Rail		175
" Sections.....		44
" Spiking.....		142
" Switches.....	191-193	
" Switch stands.....		193
" Ties in track.....	102, 106	
" Ties before use.....	93, 298	
" Track.....	40-46, 175	
" Track during storms.....	21, 40, 359	
" Track gauges.....		163
" Track levels.....		10
Interests of Company to be protected.....	"M"	
Interlocking Plants alterations to.....		622
" " care of.....		632
" " failures.....	623, 626	
" " interference with.....		31
" " maintenance of.....	677-681	
" " out of service.....		672
" " persons allowed in.....		636
Interlocking Signals, definitions and indications.....		601-611
Interlocking switches, disconnection of.....		624
" " repairs to.....		627
Insensibility, treatment in cases of.....		713
Insulated joints, maintenance of.....	29, 132, 133, 692	
Insulation of handcars, etc.....	"M.M."	
Intoxicants, use of.....	"G"	

Jacks, track
 Joints.....
 " method
 " insulat
 " insulat
 " spiking
 Joint ties....
 " tam
 " spac
 Junction Sign

 Kinks in rails

 Lamps.....
 Lanterns.....
 Laying rail...
 Laying tieplai
 Lead Rails...
 Leads, Switch
 Leaks in tank
 Leaving the s
 Length of eas
 " inne
 " rail
 Lenses.....
 Levels, track.
 Levers, signal
 " testin
 " operat
 Lights in inter
 " on fixe
 Lighting of lai
 Lining of curv
 " ends
 " track
 Lining, Gaugir
 Livestock on l