

MUNICIPAL DEPARTMENT

HIGHWAY CULVERTS AND BRIDGES*

By A. W. CAMPBELL, Ontario Road Commissioner.
(Continued from last issue.)

MATERIALS.

The materials available for culvert construction, in addition to timber, are sewer pipe, concrete pipe, iron pipe, brick, stone and concrete. Culverts are sometimes made of one of these materials alone, or of two or more in combination. When the dimensions of a bridge are reached, concrete and stone abutments and piers, with iron or steel superstructure, or stone, brick, or concrete alone or in combination, are the materials gaining favor.

SEWER PIPE.

For the small culverts, sewer pipe is very economical and durable if well laid. To render them secure against the test of a Canadian climate, they should be laid with a good grade, and the ends protected with concrete, stone or brick headwalls with deep aprons. The joints should be made water tight with cement. These precautions will provide against the action of frost and will prevent the culvert being undermined by water passing along the outside of the pipe, either from the ends or through the joints. Care should be taken to excavate a concave bed for the pipe to rest in, always laying the spigot ends up grade.

The pipe at the outlet should be set flush with the surface of the ground. If set higher than the surface the fall of water will wash out a depression and will in time undermine the end of the culvert. A too rapid grade will cause the same result. It is frequently well to cobble-pave the outlet, where this undermining action is likely to occur.

CEMENT-CONCRETE PIPE.

Excellent culvert pipe of concrete can be manufactured in any gravel pit under the direction of the municipal engineer. The pipes are three or four inches in thickness according to diameter, which latter may safely and conveniently reach 3 ft.

The implements required are of the simplest kind. The most important are two steel spring cylinders, one to set inside the other, leaving a space between the two equal to the thickness of the concrete pipe. By "spring-cylinder," it may be explained, is meant such a cylinder as would be formed by rolling an iron plate into a tube without sealing the joint. With the smaller of these cylinders the edges overlap or coil slightly, but they are so manufactured that the edges may be forced back and set into a perfect cylinder.

These two cylinders with joints flush are set on end, the one centrally inside the other, and on a firm board bottom. The concrete, made of first class cement and well screened gravel, is then tamped lightly but firmly into the space or mould between the two cylinders. The tamping iron used to press the concrete into place is so shaped as to fit closely to the cylinders.

The concrete is allowed to stand in the mould for a few hours, when the cylinders are removed, the outer and larger cylinder by inserting an iron wedge into the joint and forcing the edges apart, the inner cylinder by inserting the wedge into the joint and turning the edges so as to allow them to again overlap, returning to the shape of the coil. The outer cylinder having thus been made larger and the inner one smaller, they can readily

be taken away, and the concrete pipe is then left until thoroughly hardened.

Just such a number of pipe as are actually required for the season's work need be manufactured; the implements required are inexpensive, and the pipe may be made by the municipality for actual cost, which, after a little experience, can be reduced to a very small amount. Culverts of concrete pipe are laid in a manner similar to those of sewer pipe.

ARCH CULVERTS OF STONE AND CONCRETE.

There is no departure which would enrich the highways more than the general use of stone and concrete for the construction of bridges and culverts. They cost more in the first instance, but the longer life, the fewer repairs needed, the greater convenience, the lesser liability to accident, render them in every way desirable.

Concrete and stone are the only materials with which really permanent work of this nature can be constructed. Bridges and culverts of rubble masonry have existed in Scotland and Ireland with scarcely any repairs for more than a century, since before the time of Telford and Macadam. Concrete bridges and roadbeds built by the Romans nearly 2,000 years ago are still in use in spite of efforts to destroy them in military operations. The cost of this class of work is constantly decreasing through the cheapening and improving of cement, through the lessened expense of procuring stone and crushing it, and through growing experience in the use of cement. In Scotland it is common for farmers to contract for rubble-concrete bridges, provide the stone, and hire masons to do the work. In this way the entire expenditure is kept in the locality, among the people who pay the taxes, and is, therefore, in spite of a slightly greater cost, not unpopular. Up to forty foot spans, this construction is not difficult.

In the construction of a stone arch, the first consideration is the foundation. The depth to which the excavation must be made will depend chiefly upon the span

of the arch and the nature of the natural soil on which it will rest. The chief object is that it shall be secure. If bed rock comes to the surface it may be safe to rest the base of the arch upon it without any further excavation. A firm hardpan may exist a short distance below the surface of the ground. But a quicksand, or other insecure footing, may necessitate the sinking of piles, or the placing of a wide, and perhaps deep, concrete base. But the foundation must be sufficient to provide that the washing of the water cannot undermine it, that the lateral thrust of the embankments cannot move it, nor the weight of loads cannot cause it to sink. No more definite rule can safely be given than to make the most of local circumstances, with always a fair margin for safety.

Full-centre arches, that is, entire semi-circles, are easily formed, possess great strength, and have little lateral thrust, but with wide spans they necessarily rise to a correspondingly great height, and cannot always be employed. A segmental or flat arch will lessen the rise, but has a considerable lateral thrust which necessitates very strong abutments. A compound arch, made up of a number of different circles, when rightly proportioned, combines the advantages of the two, reducing the height, and at the same time having an excellent appearance. The thickness of the arch and abutments depends on a number of details, the chief of which are the form and size of the arch, the quality of the material composing it, and the character of the workmanship. The haunches or shoulders should be built from the spring of the arch half way to the top.

(To be Continued.)

THE ENGINEERS' CLUB OF TORONTO.

The regular monthly meeting of the Engineers' Club of Toronto, which should have been held on Tuesday of this week, was cancelled on account of the Industrial Exhibition. The next regular meeting is announced to take place on Tuesday, October 3rd. Mr. Willis Chipman, 103 Bay street, is secretary of the club.



"BEAVER" PORTLAND CEMENT

A HIGH GRADE PORTLAND CEMENT

Manufactured by THE BEAVER PORTLAND CEMENT CO., LIMITED - WORKS: MARLBANK, ONT.

SOLE SALES AGENT: COMMERCIAL WOOD & CEMENT COMPANY

Canada Life Building, Montreal.

Largest Works in Canada.

Write for Prices.

BELLHOUSE, DILLON & CO., 30 St. Francois Xavier St., Montreal

Sole Agents for the Compagnie Generale des Asphaltes de France (Rock Asphalt).

PORTLAND CEMENT NORTH'S CONDOR

Paving and Fire Brick a Specialty

NORTH'S "CONDOR" BRAND AWARDED FIRST PRIZE AND GOLD MEDAL AT THE ANTWERP EXHIBITION



"GERMANIA" BRAND

HIGHEST CLASS PORTLAND CEMENT

MCGILL UNIVERSITY TESTS, 1898:

Fineness:—residue on 100 sieve, 4.45%.

Tensile strength: neat: 7 days, 629 lb.

28 " 773 lb.

—OF ALL FIRST CLASS DEALERS.—



"BURHAM" BRAND

THE BEST LONDON PORTLAND CEMENT

As used for the following work: Keewatin Power Co.'s dam at Lake of the Woods; Canada Paper Co.'s dam at Windsor Mills; Government Breakwater, Buffalo; Dry Docks, Brooklyn and League Island; Hudson River Tunnel; and a vast amount of railway work, and mileage of Street Paving throughout Canada and the States.

OF ALL FIRST CLASS DEALERS.

* Paper read before the Association of Ontario Land Surveyors.