From the Hare's Ears, off Ferryland Head, to Cape Broyle, the Coarse is Cape Broyle. N. \(\frac{1}{4}\) W. distant 2\(\frac{3}{4}\) Miles. This Cape is high Table Land, and make h in a Saddle, either coming from the Northward or Southward. From North Part of the Cape, ESE. \(\frac{3}{4}\) of a Mile, lies a small Rock, called Main is wards of which is only 3 Fathom Water; but between it and the Main is wards of 20 Fathom Water. About \(\frac{3}{6}\) of a Mile to the NE. of the North Part of Cape Broyle lieth a Ledge of Rocks, called Horse Rocks, on which you have from 7 Horse Rocks to 14 Fathom Water. In bad Weather the Sea breaks very high on these Rocks. The Mark for these Rocks is a white House on Ferryland Downs, open with Stone Islands, and the Head of Cape Broyle Harbour open will carry you on them.

From the North Part of Cape Broyle to the South Part of Brigus Head, the Brigus Head Course is NW. by N. Distance 1½ Mile. These Points form the Entrance into Cape Broyle Harbour, which runs 3¾ Miles up. About 1½ Mile within the Entrance on the North Shore, is a Cove, called Admiral's Cove, in which You may anchor in about 12 Fathom Water, good Ground; but here you will he open to the South-East. The best Anchorage is above the Narrows, in about 7 Fathom Water. The only Danger in sailing up the Harbour is a Ledge, called Saturday's Ledge, and lieth about a Cable and a½ Length without the Narrows, on the North Shore; if you are coming in from the Northward, keep the Saddle on Brigus Head open with the Point of Admiral's Cove, it will carry you clear off this Ledge. After you are above the Narrows, you may anchor in about 7 Fathom Water, good Ground. Here you will be very handy for wooding and watering.

Brigus by South is a small Harbour, only fit for Boats, and lieth close to the Brigus Northward of Brigus Head.

South.

Cape Neddick lieth N. 5 Miles from Cape Broyle, and N. 2 W. Distance 7\frac{3}{4} Cape Ned-Miles from the Hare's Ears off Ferryland. This Cape is Table Land, of a dick. moderate Height, and steep towards the Sea.

From Cape Neddick to Baline Head the Course is N. 15 E. Distance 1½ Mile. Baline Head. Baline Cove is about ½ Mile to the Northward of Baline Head. This is but a small Cove, fit only for Boats.

From Cape Neddick to the outer Point of Great Island the Course is N. 40 E. Great Island Distance $2\frac{1}{2}$ Miles. This Island is about $\frac{1}{2}$ a Mile in Length, and of a moderate Height.

From Baline Head to Isle Spear the Course is N. ½ E. Distance one Mile. Isle Spear. Nearly within this Island a Fishery is carried on, but no safe Anchorage, the Bottom being rocky.

Toad's