

TO CROSS A WALL.

The stretcher is lowered with the foot about one pace from the wall. Nos. 1 and 2 bearers then take hold of the foot of the stretcher, and No. 3 of the head; the stretcher is raised till the foot is placed on the wall. No. 1 then climbs over the wall and takes hold of the foot of the stretcher, while Nos. 2 and 3 support the head; the stretcher is then carried forward till the head rests on the wall, No. 1 supporting the foot. Nos. 2 and 3 then climb over the wall and take hold of the head of the stretcher, which is then slowly lifted off the wall on to the ground, and the bearers take their usual places.

TO LOAD A WAGON.

The stretcher is lowered with the foot one pace from the end of the wagon. Nos. 1 and 2 take hold of the foot of the stretcher, No. 3 the head. The stretcher is then raised and carried forward till the front wheels rest on the floor of the wagon. No. 1 then jumps into the wagon, while No. 2 goes to the head of the stretcher and helps No. 3. The stretcher is then pushed slowly into the wagon. If the tailboard cannot be shut, the stretcher must be lashed firmly to the sides of the wagon.