




*Fig. 2.—Jacket on Boiler at the Grand Opera House, New York.*




*Fig. 5.—Method of Using Mineral Wool by Means of Wooden Boxes. Plan Well Adapted for Use of Pipes Exposed to the Weather.*



*Fig. 1.—Use of Mineral Wool Inside of Wooden Collars. Plan Pursued by the New York Steam Company with its Underground Pipes.*



*Fig. 3.—Canvas and Sheet Iron Cover Used on Boilers of the Pennsylvania Railroad Company.*



*Fig. 4.—Mineral Wool within Wooden Collars, made in Sections and Protected next to the Pipes by Tin or Sheet Iron.*

NON-CONDUCTION.—DIFFERENT METHODS OF APPLYING MINERAL WOOL.